



Slip/Fall Protection for Your Guests and Staff.

Visit www.slipsafetile.com to Purchase

SlipSafeTile slip resistant tile treatment is an easy-to-use, low-cost solution that can be quickly and safely applied to a variety of hard surfaces, helping to prevent unsafe, slippery conditions, when wet.

This mop on/mop off treatment works microscopically and can be used on ceramic tile, quarry, terrazzo, marble and other natural stone to help prevent slippery conditions on wet floors and surfaces. It works extremely well on unpainted concrete surfaces.

With proper application and house-keeping maintenance, the treated floor surface will have a slip co-efficient that far exceeds ADA and OSHA slip-fall safety recommendations.

SlipSafeTile Treatment is not appropriate for use on vinyl, linoleum, wood or metal. It may reduce the sheen on some marble surfaces. *Always* test a small area.

SlipSafeTile Products, LLC
Santa Clarita, CA
(661)857-0725
www.slipsafetile.com

6 GALLON PACK,
\$199
SPECIAL WITH
REBATE

Limited time, call Art Herrera
for details

661-857-0725

- Easy to apply - mop on and rinse off
- Not a coating - nothing to wear off, lasts one year
- Low cost protection
- Reduces insurance and litigation expenses
- Creates tread-like sure footing
- Does not alter surface appearance
- Apply annually for best results
- Environmentally friendly, non-toxic and odorless
- Coverage: 300 sq. ft. per gallon



Easy to Apply

Simply Mop On - Rinse Off

SlipSafeTile

TREATMENT APPLICATION:

- Treatment application time frame reactions vary with the multitude of tile products in use.
- Testing in a small area is necessary to determine the time needed for proper results.
- Remove all soil, grease, oils.
- Pour a small amount of SlipSafeTile treatment to a small test area. Brush the wet surface, let stand 3-6 minutes.
- Start with dry tile
- Slide shoe with firm foot pressure across wet tile surface to test slip resistance, the resistance should be dramatic.
- Maximum slip resistance is normally attained within the 3-6 minute time frame. However some porcelain tiles may take longer.
- Treat remaining areas in sections that will be mopped on, let stand with time frame as test area. 100 square feet at a time, eg. Front Entrance, Bathrooms.
- Keep the treatment area wet, **do not let product dry on the tile** as there will then be the need to reapply.
- Thoroughly rinse the treated area with clean water to remove all the treatment solution, use clean water.
- **IMPORTANT: Do not let solutions dry on surface; reapply if needed.**



Good floor housekeeping maintenance is important to maintain maximum slip resistance; or the technical term “coefficient of friction” (COF). Please contact www.slipsafetile.com with any questions regarding SlipSafeTile Treatment or application information.

SlipSafeTile Products, LLC

Santa Clarita, CA

(661)857-0725

www.slipsafetile.com